MONTANA
Department of Transportation

February 2025

MDT Civil 3D State Kit - Adjust Profile View Range

YOUTUBE VIDEO DOCUMENTATION

TABLE OF CONTENTS

Table of Contents **2**
Overview **3**
Companion Documentation **3**
Using the Command 3

OVERVIEW

The **Adjust Profile View Range** command will adjust the minimum and maximum grid elevations for any number of profile views.

The **Adjust Profile View Range** command is developed and provided by WisDOT.

COMPANION DOCUMENTATION

YouTube Video Link: https://youtu.be/-trsKp14wIQ?si=ms4IUPEK5RgYZmvZ

USING THE COMMAND

1. Type **MDTProfileViewElevRange** at the command line or press the **Adjust Profile View Range** ribbon button.
2. Select one or more Profile Views.
3. Enter a Minimum Elevation [Same]
    a. Enter a minimum elevation value and press **<enter>**.
    b. Or select [Same] to keep the height the same.
4. Determine height by [New Elevation] <New>
    a. Maximum elevation option – New height
        i. Select New.
        ii. Enter desired grid height value and press **<enter>**.
    b. Maximum elevation option – Specific elevation
        i. Select Elevation.
        ii. Enter desired maximum elevation value and press **<enter>**.
5. Profile View grid(s) will be adjusted accordingly.