MONTANA
Department of Transportation

April 2025

MDT Civil 3D State Kit - Auto Attach XREF

YOUTUBE VIDEO DOCUMENTATION

TABLE OF CONTENTS

Table of Contents **2**
Overview **3**
Companion Documentation **3**
Using the Command 3

OVERVIEW

The **Auto Attach Xref** command simplifies the placement of drawing references by making it a one step process. **Auto Attach Xref** will place a DWG file as a reference, at the coordinates 0,0,0, as an overlay, with a relative path, on a new unique layer. The layer name takes the form: X-XREF-*filename*

The **Auto Attach Xref** command is developed and provided by MDT.

COMPANION DOCUMENTATION

YouTube Video Link: https://youtu.be/tPmISBFaqUY?si=qC9ropP4F64XvwLi

USING THE COMMAND

1. Type **MDTATTXREF** at the command line or press the **Auto Attach Xref** ribbon button.
2. Select a drawing file
    a. Browse to a DWG file and click “Open”.
3. The drawing will be referenced into the current drawing at 0,0,0, as an overlay, with a relative path, on a new unique layer.